

Operating instructions



Countdown-Timer

Status: 04.03.2021

Read the operating instructions before starting all work!

Pfalz Tec GmbH

Erligheimer Ring 9
02829 Markersdorf
Germany

Phone: +49 (0) 35829 631111

Internet: www.pfalz-tec.com

Mail: info@pfalz-tec.com


Managing Director: Dipl.-Wirtsch.-Ing. Heinz Gerke

Facebook: www.facebook.com/pfalztec/

Protection note:

This document may not be photocopied, reproduced, translated or recorded on data carriers, either in part or in full, without prior permission. Violations oblige you to pay damages.

Button functions



[PROG]	Selecting the setting mode and the individual digits
[+]	In setting mode: Enlarge the flashing spot
[-]	In setting mode: Reducing the flashing spot
[RESET]	Resetting to the start time of the timer
[START/STOP]	Start and stop the timer

Setting the timer time

Press the [**PROG**] button briefly.

The hour position in the timer's display flashes.

Use the [**+**] or [**-**] button to set the hour position to the desired value.

When the [**+**] or [**-**] key is **pressed constantly**, the left area changes up or down.

After pressing the [**PROG**] button again, the spot will flash for the minutes as described above.

After pressing the [**PROG**] button again, the seconds position flashes.

The next time you press the [**PROG**] button, the timer switches back to timer mode.

Attention: When the output is active, the [**PROG**] button is out of function and the setting mode cannot be selected.

Start and stop the countdown timer

Starting the timer with the [**START/STOP button**], the output relay of the timer is activated and the display decreases every second.

The [**START/STOP**] button stops the expiration time, the relay drops, the timer time in the display stops.

The input [**START/STOP**] has the same function as the [**START/STOP**] button.

When 00:00 00 is reached, 2 signal tones sound, the relay drops off and the display returns to the set value.

Attention: If the timer is switched at a timer time of 00:00 00 with the [**START/STOP**] button, the bell symbol flashes in the display and the relay remains active until the [**START/STOP**] button is pressed again.

Resetting the countdown timer

After stopping the expiration time with the [**START/STOP**] button, the timer will be reset to the set time **with the** [**RESET**] button.

Press all 3 buttons of the timer at the same time for about 4 seconds.

Data preservation in the event of a network failure

In the event of a power failure, the process is stopped and the active relay falls off. Display:--.

After return, the last timer time before the power failure is displayed, the timer must be restarted.